

DC MAGNETIC DOOR HOLDER requires constant DC power. A 4 or 5 digit Corby Key Code releases door holder for 6 seconds and provides locked/unlocked visual status. 1N4002 diode must be used. If power is lost, unit will be in the fail-safe mode.

